Las Vegas Roulette
© Mattel, Inc. 1979. PRINTED IN U.S.A
CHANGE BET DISPLAY
123
456
789
CHANGE BET DISPLAY
READY
ENTER
0
MOVE CURSOR
1118-4289

MATTEL ELECTRONICS®

1118-0920

INTELLIVISION™ Intelligent Television

CARTRIDGE INSTRUCTIONS

Las Vegas Roulette

Make a date with Lady Luck and meet her in your living room. You have your own Roulette table now. Watch out! If she smiles, you're golden. If she frowns, your make-believe stakes will dwindle. The excitement and suspense of Las Vegas is yours at the press of a key.

HOW TO WIN There's no discounting luck, but for more fun and a better understanding of the odds, read this booklet.

FOR COLOR TV VIEWING ONLY.

©Mattel, Inc. 1979 Hawthorne, CA 90250. **PRINTED IN U.S.A.**
All Rights Reserved.

OBJECT OF THE GAME: To increase your simulated stakes. Spin the wheel! The key is luck. If you've got it, your make-believe winnings will grow.

CHECK YOUR EQUIPMENT



MAKE SURE:

- MASTER COMPONENT is connected to TV set and power cord is plugged in.
- ANTENNA SWITCH BOX is set at GAME.
- TV set is plugged in and properly adjusted.
- LAS VEGAS ROULETTE cartridge is placed in slot, firmly engaged.
- OFF/ON switch is turned ON.

NOTE: When Keyboard Component is added to Master Component, cartridge goes into slot on the Keyboard Component, sold separately. (See instructions with Keyboard Component.)

PRESS RESET BUTTON: Title will appear on TV screen:



ADD OVERLAYS

Find two LAS VEGAS ROULETTE keyboard overlays in the cartridge package with this booklet.

Remove Hand-held Controllers from the console.

Insert an overlay into each Hand Controller (if two people are playing). Make sure the overlays fit tight and are all the way in. The overlays will be your visual guide to each game.

THE "KEYS" TO THE GAME

CHANGE BET DISPLAY: used to change Bet display to read amount of stakes and amount of total bet.

DIGIT KEYS: used to indicate amount of individual bets.



CHANGE BET DISPLAY

READY BUTTON: used to spin the wheel.

ENTER KEY: used to enter amount of stakes, select control chip, and enter amount of bet.

DIRECTION DISC: used to move chips over Roulette table. 16 directions correspond to directions on screen. Continuous movement of chip as long as Disc is pressed.

SELECT YOUR MAKE - BELIEVE STAKES!

1) EITHER PLAYER: Press DIRECTION DISC. Computer will print out on screen—

STAKE:
PLAYER 1

2) PLAYER 1 (LEFT): Press DIGIT KEYS to select make-believe stakes (amount you play with).

You may request up to $9,999 . . . however, computer cannot count past this number and will not add simulated winnings if you choose it to start. A lower stake is better, say $5,000. Press digit keys 5—0—0—0. This number will appear on the screen.

3) Press ENTER KEY to register pretend stakes.

4) PLAYER 2 (RIGHT): Select stakes in same manner.



ONE OR TWO PEOPLE CAN PLAY ROULETTE. If one person only is playing, a 0 stake must be entered for Player 2. Game will not appear on screen until ENTER key is pressed a second time.

THE ROULETTE TABLE The Numbers and The Payoff



BET DISPLAY reads out amount of individual bets on each chip unless either CHANGE BET DISPLAY button is pushed. Display then reads out AMOUNT OF STAKES and AMOUNT OF TOTAL BET.

BETTING CATAGORIES

There are 11 different categories of bets that can be placed in Roulette. Where you place a bet on the table determines its category and your odds of winning.

STREET. Pays 11 to 1 on any of 3 numbers in a vertical column. Odds: 11-2/3 to 1.

5 NUMBER. Pays 6 to 1 on 0, 00, 1, 2, or 3. Odds: 6-3/5 to 1.

LINE. Pays 5 to 1 on any of 6 numbers either side of a vertical line. Odds: 6-3/5 to 1.

SQUARE. Pays 8 to 1 on any of 4 numbers in a square. Odds: 8-1/2 to 1.

0/00 SPLIT. Pays 17 to 1 on either 0 or 00. Odds: 18 to 1.

STRAIGHT. Pays 35 to 1 on any single number. Odds: 37 to 1.

HORIZONTAL SPLIT. Pays 17 to 1 on either of 2 horizontally adjacent numbers. Odds: 18 to 1.

COLUMN. Pays 2 to 1 on any number in the horizontal columns 1-34, 2-35, or 3-36. Odds: 2-1/6 to 1.

VERTICAL SPLIT. Pays 17 to 1 on either of 2 vertically adjacent numbers. Odds: 18 to 1.

DOZENS. Pays 2 to 1 on any number in the groups 1-12, 13-24, or 25-36. Odds: 2-1/6 to 1.

HALVES. Pays even (the amount you bet) on any number in the groups HIGH (19-36) or LOW (1-18), RED or BLACK, or ODD or EVEN. Odds: 1-1/9 to 1.

HOW TO PLACE YOUR PRETEND BET

Roulette table will appear on screen with the wheel stationary.

Three chips will appear for each player, beside the Roulette table — Player 1 on left (blue), Player 2 on right (white). Each chip is used to place one bet. Top chip for each player is a different color, indicating that it is the controllable chip. Player 1 control chip appears light blue. Player 2 control chip appears gray.

With 2 people playing, readouts for AMOUNT OF INDIVIDUAL BETS will appear along the bottom of the screen in each player's color. With 1 person only playing, readout will appear for that player only. Before bets are placed, readouts appear as 0.

PLAYERS MAY BET SIMULTANEOUSLY.

1) Use DIRECTION DISC to position control chip on Roulette table. Press Disc in direction you want control chip to move. Chip will move continuously until you stop pressing Disc, then settle in the nearest legal betting position.

EXAMPLE: To place a STREET bet on numbers 13, 14, and 15, position control chip, as shown, above the number 15.

2) When control chip is in desired position, PRESS DIGIT KEYS to indicate the amount of your pretend bet. This amount will appear in black in the readout for first chip.



Minimum bet per chip played is $1.

Maximum bet per chip played is $99.

3) PRESS ENTER KEY. Readout for amount of first bet will change from black to player's color. Next control chip will automatically change color.

4) Repeat steps 1 - 3 to place second and third bets.

5) If you do not want to play a particular chip, PRESS ENTER AGAIN, after chip has changed color. Control will move on to the next chip.

When all bets have been placed and ENTER key has been pressed three times, last control chip will turn same color as other two chips.

6) After both players have entered all bets, both players PRESS READY BUTTON. (One player only — press READY button on your Hand Controller only.)

Roulette wheel will START SPINNING. Roulette ball will appear beneath wheel, traveling right to left. You hear the RAPID CLICKING of the wheel turning.

7) Wheel slows to stop. Ball skips between numbers, then lands on winning number. You hear the sound of the BALL DROPPING INTO THE WINNING SLOT. Winning chips and winning bets on Bet Display BLINK.

If you win, your winnings are added to your stake.

If you lose, your bet is subtracted from your stake.

To check your stake at any time, PRESS EITHER CHANGE BET DISPLAY BUTTON.

NOTE: To bet more than $99 on one position, use additional chips. With all 3 chips on one space, betting limit is $297.

HOW TO CHANGE YOUR PRETEND BET

After each spin of the wheel, you can repeat or change your bet.

To repeat all bets, simply press the READY button. Wheel will spin again, with all bets unchanged.

TO CHANGE POSITION OF CHIP

1) Press ENTER key, until chip you wish to move changes color. (All chips turn the same color after ENTER key is pressed 3 times. To return control to first chip, press ENTER again.)

2) Use DIRECTION DISC to move control chip to desired position.

3) Press ENTER key. Control will move to next chip.

If you wish to leave the remaining 2 bets intact, continue pressing ENTER key until all chips are the same color.

TO CHANGE AMOUNT OF BET

1) Press ENTER key, until chip you wish to change changes color. BET DISPLAY for that individual bet will turn black.

2) Press DIGIT KEYS for new amount of bet. New amount will replace old amount on Bet Display readout.

3) Press ENTER key. Bet Display for that individual bet will change to color of your chips and control will move to next chip.

NOTE: You may remove all chips from the table, using the Direction Disc, to sit out a spin of the wheel. If you do this, you MUST CHANGE YOUR BETS TO 0, or the computer will continue to deduct the total amount of your bets from your stake.

WINNING

You break the bank at $9,999. Beyond this point, you may continue playing, but the computer will no longer add on your winnings.

LOSING

Computer does not give credit. If you have $48 left in your stake and you try to enter a bet of $75, computer will change your bet to $48. If you lose this, you're out! Your Hand Controller will no longer operate the game. To start a new game, press RESET button on Master Component, and enter new stakes.

ROULETTE PAY CARD

(To help you figure your winnings on bets with higher stakes. Your winnings **plus** the amount of your winning bet are added to your stake.)

TYPE OF BET	STRAIGHT		SPLIT		STREET		SQUARE		LINE	
ODDS	35 to 1		17 to 1		11 to 1		8 to 1		5 to 1	
	Bet	Pays	Bet	Pays	Bet	Pays	Bet	Pays	Bet	Pays
	1	35	1	17	1	11	1	8	1	5
	2	70	2	34	2	22	2	16	2	10
	3	105	3	51	3	33	3	24	3	15
	4	140	4	68	4	44	4	32	4	20
	5	175	5	85	5	55	5	40	5	25
	6	210	6	102	6	66	6	48	6	30
	7	245	7	119	7	77	7	56	7	35
	8	280	8	136	8	88	8	64	8	40
	9	315	9	153	9	99	9	72	9	45
	10	350	10	170	10	110	10	80	10	50
	11	385	11	187	11	121	11	88	11	55
	12	420	12	204	12	132	12	96	12	60
	13	455	13	221	13	143	13	104	13	65
	14	490	14	238	14	154	14	112	14	70
	15	525	15	255	15	165	15	120	15	75
	16	560	16	272	16	176	16	128	16	80
	17	595	17	289	17	187	17	136	17	85
	18	630	18	306	18	198	18	144	18	90
	19	665	19	323	19	209	19	152	19	95
	20	700	20	340	20	220	20	160	20	100



90 DAY LIMITED WARRANTY

Mattel Electronics® warrants to the original consumer purchaser of any cartridge or cassette it manufactures that the product will be free of defects in material or workmanship for 90 days from the date-of-purchase. If defective, return the product along with proof of the date-of-purchase to either your local dealer or, postage prepaid, to:

Consumer Adjustment Center
5150 Rosecrans Avenue
Hawthorne, California 90250

for replacement. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty does not cover damage resulting from accident, misuse or abuse.

HOW TO ORDER YOUR REPLACEMENT OVERLAYS

Complete the order form below and mail it with your check or money order for $1.25 per set of 2 overlays. California residents add 6% sales tax. Address check or money order to Mattel Electronics®, Box 2350, Hollywood, CA 90025. Allow 4-6 weeks for delivery. Offer subject to availability.

Mark quantity ordered

LAS VEGAS ROULETTE	1118-4289 ____ sets	NBA BASKETBALL	2615-4289 ____ sets
ELECTRIC CO. MATH FUN	2613-4289 ____ sets	NHL HOCKEY	1114-4289 ____ sets
ELECTRIC CO. WORD FUN	1122-4289 ____ sets	BACKGAMMON	1119-4289 ____ sets
NFL FOOTBALL	2610-4289 ____ sets	LAS VEGAS POKER & BLACKJACK	2611-4289 ____ sets
HORSE RACING	1123-4289 ____ sets	ARMOR BATTLE	1121-4289 ____ sets
CHECKERS	1120-4289 ____ sets	MAJOR LEAGUE BASEBALL	2614-4289 ____ sets
AUTO RACING	1113-4289 ____ sets	SPACE BATTLE	2612-4289 ____ sets

Amount enclosed _____ Total sets ordered _____

Your name _____

Address _____

City _____ State _____ Zip Code _____

MATTEL ELECTRONICS®

INTELLIVISION™

Intelligent Television



Other electronic games
available from Mattel Electronics.®
Look for them!